LIGHT MY BRICKS

LEGO LION KNIGHTS' CASTLE #10305 LIGHT KIT

INSTALLATION GUIDE

Light My Bricks

LEGO THE LION KNIGHTS' CASTLE 10305 INSTALLATION GUIDE

Hi There!

We're here to help you get started on the LEGO

The Lion Knights' Castle 10305 Light Kit.

This PDF details the instructions for the LED light kit only. If you are wishing to purchase this product, please click here to view the product page.

If you run into any issues, please refer to the troubleshooting section towards the end of this guide.

Have fun and enjoy!

PACKAGE CONTENTS:

1 x White 30cm Bit Light
2 x Yellow 30cm Bit Light
2 x Blue 30cm Bit Light
13 x Orange 30cm Bit Light *
3 x Warm White 30cm Large Bit Light
9 x Orange 30cm Large Bit Light *

2 x 2-Port Expansion Board
9 x 6-Port Expansion Board *
4 x Flicker Effects Board

6 x 5cm Connecting Cable
1 x 15cm Connecting Cable
3 x 30cm Connecting Cable
5 x 50cm Connecting Cable *

1 x USB Power Cable

14 x Adhesive Squares

ASSORTED BRICKS:

- 30 x Round Plate 1x1 w/ Open Stud - Black *
- 1 x Candle Flame
- 2 x Round Plate 1x1 - Trans Orange
- 4 x Round Plate 2x2 w/ Rounded Bottom - Trans Clear
- 4 x Tile 1x1 W Clip Round Edges - Black
- 4 x Plate 1x1 Mod Rounded w Handle - Black
- 1 x Plate 1x2 MW Stud Jumper - Black
- 1 x Round Plate 1x1 - Trans Blue

* Indicates components which include spares

Contents

Before You Begin 5

Blueprint 8

Instructions 10

Final Product 72

Troubleshooting 73

Contact 78

Before You Begin



Laying cables in between and underneath bricks

Cables can fit in between and underneath LEGO® bricks, plates, and tiles providing they are laid correctly between the LEGO® studs. Do NOT forcefully join LEGO® together around cables; instead ensure they are laying comfortably in between each stud.

CAUTION: Forcing LEGO® to connect over a cable can result in damaging the cable and light.

Connecting Cable Connectors To Expansion Boards

Take extra care when inserting connectors to ports of Expansion Boards. Connectors can be inserted only one way. With the expansion board facing up, look for the soldered "=" symbol on the left side of the port. The connector side with the wires exposed should be facing toward the soldered "=" symbol as you insert into the port. If a plug won't fit easily into a port connector, do not force it.

Incorrectly inserting the connector can result in bent pins inside the port or possible overheating of the expansion board when connected.

Before You Begin

Connecting Cable Connectors To Strip Lights

Take extra care when inserting connectors to ports on the Strip Lights. Connectors can be inserted only one way. With the Strip Light facing up, ensure the side of the connector with the wires exposed is facing down. If a plug won't fit easily into a port connector, don't force it. Doing so will damage the plug and the connector.





Connecting Micro Cable Connectors To Micro Expansion Board Ports

Take extra care when inserting the micro connectors to micro ports of Micro Expansion Boards. Connecting Micro Bit Lights to Micro Expansion Boards is similar to connecting lights and cables to Strip Lights. With the expansion board facing up, ensure the side of the connector with the wires exposed is facing down. If a plug won't fit easily into a port connector, do not force it. Use your fingernail to push the plastic part of the connector to the micro port.

Before You Begin

Installing Bit Lights Under Lego® Bricks And Plates

When installing Bit Lights under LEGO® pieces, ensure they are placed the correct way up (Yellow LED component exposed). You can either place them directly on top of LEGO® studs or in between.



BLUEPRINT


Main Castle Area (w/ Bridge)
USB Power Cable (Power Source)
2-Port Exp.
50cm
6-Port Exp.
50cm
6-Port Exp.
2 x Orange 30cm Bit Light
Flicker EFX
5cm
Flicker EFX
5cm
6-Port Exp.
15cm
30cm
6-Port Exp.
50cm
2 x Orange 30cm Bit Light
3 x Orange 30cm Bit Light
4 x Orange 30cm Large Bit Light
Orange 30cm Large Bit Light
Blue 30cm Bit Light
Blue 30cm Bit Light
2 x White 30cm Large Bit Light (2 Spotlights at the front)
cont.

BLUEPRINT


Secondary Castle Area
50cm
30cm
6-Port Exp.
Flicker EFX
5cm
6-Port Exp.
6-Port Exp.
5cm
2 x Yellow 30cm Bit Light
6-Port Exp.
Flicker EFX
2 x Orange 30cm Bit Light
Orange 30cm Large Bit Light
Orange 30cm Bit Light
2 x Orange 30cm Large Bit Light
2 x Orange 30cm Bit Light
White 30cm Bit Light
(Spotlight on Wheel)
Orange 30cm Large Bit Light

INSTRUCTIONS

To ensure a smooth installation of your light kit, please read and follow each step carefully. If you run into any issues, please refer to the online troubleshooting guide.

1

2



Orange 30cm Large Bit Light



Black Round Plate 1x1
w/ Open Stud



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON





3











Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

4

Orange 30cm Large Bit Light

Black Round Plate 1x1 w/ Open Stud

Thread both of the cables through the Open Stud

Black Round Plate 1x1 w/ Open Stud









Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON









6-Port Expansion Board



5





Orange 30cm Large Bit Light

Plate 2x2 W Rounded Bottom - Trans Clear

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON










6







Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON






7



2-Port Expansion Board



30cm Connecting Cable



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

Adhesive Square





8









Black Round Plate 1x1
w/ Open Stud







Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON









Push the cables up to the ceiling so they are not visible






Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

9

6-Port Expansion Board



15cm Connecting Cable









50cm Connecting Cable







Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

10






Thread the 50cm Connecting Cable from the previous step through the Round Plate 1x1 w/ Open Stud - Black





Black Round Plate 1x1 w/ Open Stud






Ensure to only lift up the plate as much as shown. Lifting too far will cause the Large Orange Bit Light you installed previously to come loose.




Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON





11

Orange 30cm Large Bit Light



Round Plate 1x1 - Trans Orange





Exclude the 15cm Connecting Cable from twisting



Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

12



Orange 30cm Bit Light

Plate 2x2 W Rounded Bottom - Trans Clear









Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

13








Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON



6-Port Expansion Board



14











Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON





Orange 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud

15

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

16














Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

17









Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.

18

2-Port Expansion Board

USB Power Cable







Connect the other end to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

19



Orange 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud





Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

20








Connect the Orange 30cm Bit Light from the previous step to the 'OUT' port of the Flicker Effects Board









Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

21



Orange 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

22











Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON










Connect the Orange 30cm Bit Light from Step 21 to the 'OUT' Port of the Flicker Effects Board

23



Orange 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

Connect the other end to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)

24






Connect the Orange 30cm Bit Light from Step 23 to the 'OUT' Port of the Flicker Effects Board



5cm Connecting Cable

Connect the 5cm Connecting Cable to the 'IN' Port of the Flicker Effects Board




Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

Connect the other end of the 5cm Connecting Cable to the 6-Port Expansion Board

Twist all the cables but exclude the 50cm Connecting Cable



Hide the Cables and Boards behind the pillar











Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

25

Orange 30cm Bit Light

Black Round Plate 1x1
w/ Open Stud







Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

26



Black Round Plate 1x1
w/ Open Stud



Black Round Plate 1x1
w/ Open Stud











Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON







Flicker Effects Board



Connect the two Orange 30cm Bit Lights from Step 25 to the 'OUT' Port of the Flicker Effects Board




27

Connect the 5cm Connecting Cable to the 'IN' Port of the Flicker Effects Board

5cm Connecting Cable





30cm Connecting Cable





Legend — DISCONNECT · CONNECT / RECONNECT · TURN / FLIP · DIRECTIONAL · TWIST / BRAID · POWER ON TEST · NOTE ICON





Blue 30cm Bit Light

Blue 30cm Bit Light

Round Plate 1x1 - Trans Light Blue













28

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.

Exclude the 30cm Connecting Cable from twisting




29

Warm White 30cm Large Bit Light

Black Round Plate 1x1 w/ Open Stud

Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

Black 1x1 Plate Modified Plate Rounded w/ Handle



Black 1x1 Tile w/ Clip Rounded Edges



Plate 1x2 MW Stud Jumper - Black



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

30





















Legend DISCONNECT · CONNECT / RECONNECT · TURN / FLIP · DIRECTIONAL · TWIST / BRAID · POWER ON TEST · NOTE ICON

31








32

Warm White 30cm Large Bit Light

Black Round Plate 1x1 w/ Open Stud

Black 1x1 Plate Modified Plate Rounded w/ Handle

Black 1x1 Tile w/ Clip Rounded Edges

Legend DISCONNECT · CONNECT / RECONNECT · TURN / FLIP · DIRECTIONAL · TWIST / BRAID · POWER ON TEST · NOTE ICON






33









Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.








34

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

Orange 30cm Bit Light

Black Round Plate 1x1
w/ Open Stud





35



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON











Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

37












Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON





38



39






Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

Orange 30cm Large Bit Light

Round Plate 1x1 - Trans Orange





40



Orange 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

41





Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON











42

Legend → DISCONNECT → CONNECT / RECONNECT TURN / FLIP → DIRECTIONAL TWIST / BRAID POWER ON TEST NOTE ICON

43



6-Port Expansion Board



5cm Connecting Cable





2x Adhesive Squares









Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

44

30cm Connecting Cable



50cm Connecting Cable



Enclude the 30cm and 50cm Connecting Cables from twisting



50cm Connecting Cable

Pull one of the 50cm Connecting Cables out the side





Pull the 30cm and other 50cm Connecting Cable up the wall



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON





45

Black Round Plate 1x1 w/ Open Stud



Black Round Plate 1x1 w/ Open Stud



Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

46







Thread the 30cm Connecting Cable inbetween the bricks



Thread the 50cm Connecting Cable through the Black Round Plate 1x1 w/ Open Stud

Black Round Plate 1x1 w/ Open Stud





Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

47

5cm Connecting Cable

Connect the 5cm Connecting Cable to the 'OUT' Port of the Flicker Effects Board

Connect the other end to the 6-Port Expansion Board

Flicker Effects Board

6-Port Expansion Board







Connect the 30cm Connecting Cable to the 'IN' Port of the Flicker Effects Board



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

48

Orange 30cm Large Bit Light

Black Round Plate 1x1
w/ Open Stud













Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON








49

Orange 30cm Large Bit Light

Plate 2x2 W Rounded Bottom - Trans Clear







Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

50

Orange 30cm Bit Light

Black Round Plate 1x1
w/ Open Stud





Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

51







52

Orange 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud

Candle Flame



Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON





Thread the cable beneath the door






53

Legend → DISCONNECT → CONNECT / RECONNECT TURN / FLIP → DIRECTIONAL TWIST / BRAID POWER ON TEST NOTE ICON

If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.

54





55

Take a spare Expansion Board with a Power Source and connect it to the 50cm Connecting Cable to test the lights





Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.








Black Round Plate 1x1 w/ Open Stud



56

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

57



White 30cm Bit Light

Black Round Plate 1x1 w/ Open Stud



Black 1x1 Plate Modified Plate Rounded w/ Handle



Black 1x1 Tile w/ Clip Rounded Edges





Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

58









Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⇲ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

59

6-Port Expansion Board





5cm Connecting Cable

Connect the 5cm Connecting Cable to the 'IN' Port of the Flicker Effects Board

Connect the other end to the 6-Port Expansion Board

Flicker Effects Board







60

Orange 30cm Large Bit Light



Black Round Plate 1x1 w/ Open Stud

Legend DISCONNECT · CONNECT / RECONNECT · TURN / FLIP · DIRECTIONAL · TWIST / BRAID · POWER ON TEST · NOTE ICON

You may need to remove the surrounding section or orange cones to connect the piece






61




Black Round Plate 1x1 w/ Open Stud

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

Connect the Orange 30cm Large Bit Light to the 'OUT' Port of the Flicker Effects Board



62

Yellow 30cm Bit Light



Black Round Plate 1x1 w/ Open Stud





2x Adhesive Squares



2x Adhesive Squares



Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

Hide the Cables and Boards above where the ceiling is





63

2x Adhesive Squares






Legend — DISCONNECT — CONNECT / RECONNECT — TURN / FLIP — DIRECTIONAL — TWIST / BRAID — POWER ON TEST — NOTE ICON

If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.



Connect the other end to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)

Legend → DISCONNECT → CONNECT / RECONNECT ↻ TURN / FLIP → DIRECTIONAL ⤢ TWIST / BRAID ✳ POWER ON TEST ✎ NOTE ICON

FINAL PRODUCT

This finally completes installation of the Light My Bricks

LEGO Lion Knights' Castle 10305 Light Kit.



TROUBLESHOOTING

Light My Bricks lighting kits contain individual components that are very small and can be easily damaged if not handled correctly.

To prevent unnecessary damage to components, we highly recommend that the User Guide section, **"Important things to note"** is read carefully. Follow the handling procedures in the User Guide to help prevent faults and damages to your Light My Bricks components.

If you are experiencing issues with your Light My Bricks set, watch our troubleshooting video here or read on for a list of common causes to help you troubleshoot.

Troubleshooting

Firstly, ensure that the batteries have power using a battery charge gauge.

If the batteries have no power, replace the batteries.

If the batteries still have power, check to see if the batteries have been inserted correctly into the battery pack.

Check For CR2032 Batteries Using The Flat Battery Pack

Inside the battery pack is a symbol indicating which side the (round) CR2032 battery should be inserted. Check that the "+" side of the battery pack has the battery with the "+" symbol facing downwards.

On the opposite side, the "-" side of the battery pack should have the battery flipped upside down, that is the "+" symbol facing upwards



Troubleshooting

Check For Cr2032 Batteries Using The Round Battery Pack

Inside the battery pack is a symbol indicating which side the (round) CR2032 battery should be inserted. In this case, for the stacked battery pack, ensure that BOTH batteries have the "+" symbol facing upwards.



Check for AA batteries using the AA battery pack

Inside the battery pack are symbols indicating which direction the AA battery should be inserted. The flat side of the battery should be paired with the spring side of the battery pack.

If the batteries have been installed correctly and your kit still isn't operating correctly, the next step is to check the wiring.





Troubleshooting

Check Your Wires

In order for Light My Bricks components to fit in between and underneath LEGO® bricks, the components need to be very small. Due to this nature, Light My Bricks components can be easily damaged when not handled correctly.

Be careful when removing unpacked components out of the packaging and ensure not to forcibly pull at the wires as this can damage the soldering that attach the wires to the LEDs.

If the wiring is detached from the LED itself, the light will not operate.

When connecting lights to your LEGO set, check that there are no pinched wires underneath or in between bricks and plates. When the wires are pinched and the exposed wires are touching each other, this can cause a crosswire and the lights to not function correctly.





Troubleshooting

Check Your Expansion Board Ports/ Strip Light Ports / Effects Board Ports

It is important to note that connectors can only be inserted to the expansion board, strip light, or effects board ports in one direction.

Forcibly inserting connectors in the incorrect direction will result in damaging the pins inside each of the ports on your component board.

Not only will a light connected to the damaged port not work, but if the pins inside the port are bent to a point they are touching each other, this can result in all other lights in the system to stop working. This is a short circuit.





A short circuit can also result in overheating of the board, cable or batteries. If you suspect a short circuit, DISCONNECT POWER IMMEDIATELY Batteries can fail, catch fire, or even explode if left connected to a short circuit for too long.

If you suspect you have a faulty component due to a bent pin, try the following steps:

If you look carefully inside each of the ports, each port contains 2 small pins that should be straight. You will be able to identify a faulty port if it has any bent pins.







CONTACT US

If you have an enquiry regarding the online shop, our products or a general enquiry please refer to our Frequently Asked Questions webpage here. Alternatively, you can contact our Customer Services team by visiting our online support portal here.

support.lightmybricks.com

We thank you for purchasing this product and hope you enjoy!

lightmybricks.com