



**LIGHT<sup>MY</sup>  
BRICKS**



**LEGO<sup>®</sup> UCS RAZOR CREST #75331**

**LIGHT KIT**

**INSTALLATION GUIDE**

# Light My Bricks



## LEGO® UCS RAZOR CREST 75331 INSTALLATION GUIDE

Hi There!

We're here to help you get started on the LEGO®

UCS Razor Crest 75331 Light Kit.

This PDF details the instructions for the LED light kit only. If you are wishing to purchase this product, please [click here](#) to view the product page.

If you run into any issues, please refer to the troubleshooting section towards the end of this guide.

Have fun and enjoy!





## PACKAGE CONTENTS:



- 2 x Rotating 8x8 Light Ring - Orange
- 2 x Light Ring 3x3 - Warm white
- 11 x Orange Large Bit Light - 30cm \*
- 10 x Red Bit Light - 30cm \*
- 8 x Cool White Bit Light - 15cm
- 4 x Cool White Bit Light - 30cm \*
- 2 x White Bit Light - 30cm
- 2 x Green Bit Light - 30cm
- 1 x Blue to Red Bit Light - 15cm



- 3 x 6-Port Expansion Board
- 2 x 12-Port Expansion Board
- 2 x 8-Port Expansion Board \*
- 3 x 2-Port Expansion Board
- 1 x Gun Effects Board



- 2 x Connecting Cable - 5cm
- 3 x Connecting Cable - 50cm
- 4 x Connecting Cable - 15cm
- 2 x Wireless Power Connectors



- 1x USB Power Cable  
(Power Source not Included)

## ASSORTED BRICKS:

- 8 x 1x2 Plate - Trans Clear
- 2 x1x2 Plate - Black
- 1 x 1x2 Tile - Trans Clear
- 2 x 1x1 Plate - Black
- 3 x 1x1 Round Plate - Trans Red
- 1 x 1x1 Round Plate - Trans Clear
- 2 x 2x2 Round Brick - Trans Clear
- 27 x 1x1 Round Plate w/Open Stud - Black \*
- 4 x Plate 1x1 Mod Rounded w Handle - Black
- 4 x Tile 1x1 W Clip Round Edges - Black
- 1 x 1x4 Brick - Light Grey
- 2 x 1x1 Technic Brick - Black
- 1 x 1x2 Bracket - Black

\* Indicates components which include spares

## Contents

Before You Begin	5
Blueprint	10
Instructions	11
Final Product	79
Troubleshooting	80
Contact	84

## Before You Begin



### Laying cables in between and underneath bricks

Cables can fit in between and underneath LEGO® bricks, plates, and tiles providing they are laid correctly between the LEGO® studs. Do NOT forcefully join LEGO® together around cables; instead ensure they are laying comfortably in between each stud.

*CAUTION: Forcing LEGO® to connect over a cable can result in damaging the cable and light.*




### Connecting Cable Connectors To Expansion Boards

Take extra care when inserting connectors to ports of Expansion Boards. Connectors can be inserted only one way. With the expansion board facing up, look for the soldered "=" symbol on the left side of the port. The connector side with the wires exposed should be facing toward the soldered "=" symbol as you insert into the port. If a plug won't fit easily into a port connector, do not force it.

*Incorrectly inserting the connector can result in bent pins inside the port or possible overheating of the expansion board when connected.*

## Before You Begin



### Connecting Cable Connectors To Strip Lights

Take extra care when inserting connectors to ports on the Strip Lights. Connectors can be inserted only one way. With the Strip Light facing up, ensure the side of the connector with the wires exposed is facing down. If a plug won't fit easily into a port connector, don't force it. Doing so will damage the plug and the connector.



### Connecting Micro Cable Connectors To Micro Expansion Board Ports

Take extra care when inserting the micro connectors to micro ports of Micro Expansion Boards. Connecting Micro Bit Lights to Micro Expansion Boards is similar to connecting lights and cables to Strip Lights. With the expansion board facing up, ensure the side of the connector with the wires exposed is facing down. If a plug won't fit easily into a port connector, do not force it. Use your fingernail to push the plastic part of the connector to the micro port.

## Before You Begin

### Installing Bit Lights Under Lego® Bricks And Plates

When installing Bit Lights under LEGO® pieces, ensure they are placed the correct way up (Yellow LED component exposed). You can either place them directly on top of LEGO® studs or in between.



# Before You Begin

## The Symbols Used In This Guide

When going through the following guide you will come across symbols and formats that will assist with the installation of your light kit. Take notice of them as each has a specific purpose.

### Light Kit Component

This is the most important image format as it indicates which part to use from the Light Kit. Make sure you pay close attention to which part is shown.

White 30cm Bit Light



### Connect

Used when you need to connect a LEGO piece or LMB component.



### Disconnect

Used when you need to remove a LEGO piece/ section or LMB component.



### Directional

Used to show where to route cables, place components, or move them.



### Bend/Pivot

Used when a component needs to be bent, or part folded or pivoted.



### Turn/ Flip

Will be found in the top left corner when the set needs to be rotated or flipped.



### Twist/ Braid

Seen when a set of cables need to be grouped and twisted together.



### Power On Test

Found at the end of a major step to test the lights. Will be located in the top left corner.



### Note

Notes will be found alongside the instruction photos and explain what to do.





# Before You Begin

## Repeat Step

Repeat the previous step eg. Make a spotlight, then make a second spotlight.



## Connect Focus

Used to highlight a hard to see area where a component is being connected.



## Disconnect Focus

Used to highlight a hard to see area where a component is being disconnected.



## General Focus

Used to highlight a hard to see area where a component needs to be acted on.



## General Note

This is a sample note that is used anywhere in this guide. It will explain a difficult section where photos are hard to illustrate or easily confused.

## Connect Note


The green coloured note is used when the topic focuses on a component being connected, like the shown Power Bank.

## Disconnect Note

The red coloured note is used when the topic focuses on a component being disconnected or like here, the removed pieces.

**NOTE**

Take the 5cm Connecting Cable from the 4-Port Micro Expansion Board and route it into the "IN" port of the Flicker Effects Board



**NOTE**

Connect to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)



**NOTE**


You should have these parts left over that were removed from the LEGO set






# BLUEPRINT

## Engine Section



## Main Body



## Cockpit








## INSTRUCTIONS


To ensure a smooth installation of your light kit, please read and follow each step carefully. If you run into any issues, please refer to the online troubleshooting guide.

1








2










**3**






**4**






**NOTE**

Ensure the cables run through this small opening in the Curved Tiles.



**5**






Orange 30cm Large Bit Light



Brick Round 2x2 - Trans Clear




NOTE

Ensure the LED is facing down inside the 2x2 Round Brick (away from the Trans Orange Round Plate 2x2 w/ Rounded Bottom).






**NOTE**



Ensure to only slide the Yellow Round Plate half way on the Black Technic Rod.





6




7





**8**











**NOTE**

Repeat Steps 3 - 8 for the other Booster.




**9**






**NOTE**




Connect the Bit Lights (& not the 15cm Connecting Cable) to the 6-Port Expansion Board.




**6-Port Expansion Board**



**5cm Connecting Cable**




**6-Port Expansion Board**





**NOTE**

Connect the 15cm Connecting Cable from the Ring Light to the 6-Port Expansion Board.


10





6-Port Expansion Board



5cm Connecting Cable



8-Port Expansion Board



11

**12**





**50cm Connecting Cable**









**NOTE**


Connect the 50cm Connecting Cable to any port in the 8-Port Expansion Board.











**NOTE**  
Connect the 50cm Connecting Cable to any port in the 8-Port Expansion Board.



**NOTE**  
Any loose 50cm Connecting Cable can be hidden by pulling either of the expansion board in the opposite direction.




13




**NOTE**

Connect to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)




If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section.

**13**





**14**






Light Ring 2x2 - Warm White

Round Plate 1x1 Open Stud - Black







**15**











Light Ring 2x2 - Warm White


Round Plate 1x1 Open Stud - Black








**16**



**Wireless Power Connector Pad**






**17**

Cool White 15cm Bit Light



Round Plate 1x1 Open Stud - Black








**18**










Tile 1x1 W/ Clip Round Edges - Black



Plate 1x1 Mod Rounded W/ Handle - Black










**19**




Red 30cm Bit Light











Round Plate 1x1 - Trans Red


















**20**















**21**















2 x Plate 1x1 - Black




22





**23**







2 x Round Plate 1x1 Open Stud - Black






x2












Red 30cm Bit Light




Red 30cm Bit Light









24








**25**





**26**






**Tile 1x1 W/ Clip Round Edges - Black**





**Plate 1x1 Mod Rounded W/ Handle - Black**




**Plate 1x2 - Black**



**Round Plate 1x1 Open Stud - Black**






**27**





**Wireless Power Connector Pad**







**2-Port Expansion Board**



**15cm Connecting Cable**












**NOTE**




Grab the three cables that are twisted together as well as the 50cm Connecting Cable. These will be threaded together in the next steps.






 **NOTE**


Run the 50cm Connecting Cable towards the back end of the ship for later use.



28



28





Red 30cm Bit Light



Round Plate 1x1 - Trans Red




29






Red to Blue 15cm Bit Light



Round Plate 1x1 Open Stud - Black



Round Plate 1x1 - Trans Clear











30







**NOTE**


Push wall carefully out to create a small enough gap to thread cable through.









**32**









33



34



Gun Effects Board










15cm Connecting Cable










NOTE

Connect the 15cm Connecting Cable into the "IN" port of the Gun Effects Board. Ensure to flick the switch all the way to the right.










 **NOTE**


The 50cm Connecting Cable that was run towards the back, will now be threaded and connected in the next steps.





35



12-Port Expansion Board








50cm Connecting Cable





**NOTE**

Thread the 50cm Connecting Cable through any of these technic holes.






2-Port Expansion Board





USB Power Cable




**NOTE**

Connect to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)







36



Cool White 30cm Bit Light

Round Plate 1x1 Open Stud - Black







37






Green 30cm Bit Light











NOTE

Insert the Green 30cm Bit Light inside the brick, make sure the LED is facing towards the Trans Green Plate.






38



**NOTE**

Thread the two bit light cables through any of the Technic Holes to the 12-Port Expansion Board.



39
















Cool White 15cm Bit Light

Round Plate 1x1 Open Stud - Black





40







41



42




**42**












**NOTE**

Insert the section down through opening here, and make sure to support the part from underneath through the open tail gate.





**NOTE**



Rotate the part into position then press it into place from underneath the ship through the open tail gate.



43



Brick 1x4 - Light Grey





44

2 x Technic Brick 1x1 - Black








Bracket 1x2-1x2 - Black



Plate 1x2 - Black










Wireless Power Connector Stud













**NOTE**

Thread the Wireless Power Connector Cable through any of the Technic Holes to the 8-Port Expansion Board.













45





46






**NOTE**

Connect to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)



**47**





**NOTE**

Connect to a 5V USB Power Bank, 5V USB Wall Adaptor, or USB to AA Battery Pack (sold separately)



! If you experience any issues with the lights not working and suspect an issue with a component, please try a different port on the expansion board to verify where the fault lies (with the light or expansion board). To correct any issues with expansion board ports, please view the section addressing expansion board issues in our troubleshooting section. i



## FINAL PRODUCT

This finally completes installation of the Light My Bricks

LEGO® UCS Razor Crest 75331 Light Kit.





## TROUBLESHOOTING

Light My Bricks lighting kits contain individual components that are very small and can be easily damaged if not handled correctly.

To prevent unnecessary damage to components, we highly recommend that the User Guide section, **“Important things to note”** is read carefully. Follow the handling procedures in the User Guide to help prevent faults and damages to your Light My Bricks components.

If you are experiencing issues with your Light My Bricks set, watch our troubleshooting video [here](#) or read on for a list of common causes to help you troubleshoot.



## Troubleshooting

**Firstly, ensure that the batteries have power using a battery charge gauge.**


**If the batteries have no power, replace the batteries.**

**If the batteries still have power, check to see if the batteries have been inserted correctly into the battery pack.**

### Check for AA batteries using the AA battery pack

Inside the battery pack are symbols indicating which direction the AA battery should be inserted. The flat side of the battery should be paired with the spring side of the battery pack.

If the batteries have been installed correctly and your kit still isn't operating correctly, the next step is to check the wiring.



## Troubleshooting

### Check Your Wires



In order for Light My Bricks components to fit in between and underneath LEGO® bricks, the components need to be very small. Due to this nature, Light My Bricks components can be easily damaged when not handled correctly.

Be careful when removing unpacked components out of the packaging and ensure not to forcibly pull at the wires as this can damage the soldering that attach the wires to the LEDs.

If the wiring is detached from the LED itself, the light will not operate.

When connecting lights to your LEGO® set, check that there are no pinched wires underneath or in between bricks and plates.

When the wires are pinched and the exposed wires are touching each other, this can cause a crosswire and the lights to not function correctly.




## Troubleshooting

### Check Your Expansion Board Ports/ Strip Light Ports / Effects Board Ports

It is important to note that connectors can only be inserted to the expansion board, strip light, or effects board ports in one direction.

Forcibly inserting connectors in the incorrect direction will result in damaging the pins inside each of the ports on your component board.



Not only will a light connected to the damaged port not work, but if the pins inside the port are bent to a point they are touching each other, this can result in all other lights in the system to stop working. This is a short circuit.



A short circuit can also result in overheating of the board, cable or batteries. If you suspect a short circuit, **DISCONNECT POWER IMMEDIATELY**. Batteries can fail, catch fire, or even explode if left connected to a short circuit for too long.

If you suspect you have a faulty component due to a bent pin, try the following steps:

If you look carefully inside each of the ports, each port contains 2 small pins that should be straight. You will be able to identify a faulty port if it has any bent pins.





## CONTACT US

If you have an enquiry regarding the online shop, our products or a general enquiry please refer to our Frequently Asked Questions webpage here.

Alternatively, you can contact our Customer Services team by visiting our online support portal here.

[support.lightmybricks.com](https://support.lightmybricks.com)

We thank you for purchasing this product and hope you enjoy!



[lightmybricks.com](https://lightmybricks.com)